

Bad Graphics Card? You can bypass it!

Step 1: Go to Solidworks Rx

Step 2: Go to Troubleshoot

Step 3: Select "Bypass your graphics card/driver..."

Step 4: Click the "Launch Solidworks" button that is right below it

*Keep in mind that this is needed everytime you want to open Solidworks