


Dial Calipers

1. Close the jaws of the calipers shut.
2. Unscrew the dial mechanism
3. Rotate the dial until the "0" is matched with the needle
4. Open the jaws and clamp on the part you wish to measure.
5. Tighten the set screw.
6. Read it!



Revision #4

Created 11 June 2026 23:33:59 by eharis

Updated 11 June 2026 23:46:26 by eharis